

A.C. COMPRESSOR

Our brackets are designed for the popular Sanden 508 AFTERMARKET compressor. These compressors are used by all of the specialty vehicle air conditioner companies. Most of these companies use our brackets as standard equipment with their air conditioning systems. The Sanden part numbers for the 508 compressors are:

V-groove Freon	12-9285
V-groove Freon	134-4509
Serpentine Freon	12-9537
Serpentine Freon	134-4514

Aftermarket Sanden 510 and 709 compressors, while not commonly used, will also fit our brackets. Although some factory air systems use Sanden style compressors, **THESE WILL NOT WORK** with our brackets.

